20-1 STARTING SYSTEM

For diagnostic information, refer to Section 303-06A of the Workshop Manual.



CAT/CUMMINS W/MANUAL