Battery Junction Box (BJB)

		Fuse number										
		1	2	3	4	5	6	7	8	9	10	11
		40A	30A				50A	40A	30A	20A	10A	30A
501-09-00	Rear View Mirrors											
501-11-00	Glass, Frames and Mechanisms							●				
501-12-00	Instrument Panel and Console											
501-14A-00	Handles, Locks, Latches and Mechanisms											
501-14B-00	Keyless Entry/Computer Operated Locks											
501-16-00	Wipers and Washers											
501-20A-00	Occupant Restraints – Active											
501-20B-00	Occupant Restraints – Passive – Supplemental Air Bag System											
		1	2	3	4	5	6	7	8	9	10	11
		40A	30A				50A	40A	30A	20A	10A	30A