CONNECTOR REFERENCE LIST

CONNECTOR	SECTION-PAGE
C250	60-3

Generates power to keep battery fully charged and to operate vehicle's electrical system. Output is variable and depends on speed at which rotor spins, as well as amount of current passing through rotor winding. Current flow through rotor winding is controlled by built in regulator. Stator generates alternating current, which is passed through series of rectifier diodes and converted to direct current.



4.6L 2V

3.8L



C153
GENERATOR



C154
(BLACK)
GENERATOR

4.6L 4V

Refer to Location Index, Cell 152, for Component, Connector, Splice, Ground and Base Part Number descriptions and locations.