


CONNECTOR REFERENCE LIST

CONNECTOR	SECTION-PAGE
C236 C246	62-6 13-19

Refer to Location Index, Cell 152, for Component, Connector, Splice, Ground and Base Part Number descriptions and locations.