Fuse	Amps	Circuits protected
F2.1	20	Multifunction switch (13K359)
F2.2	–	not used
F2.3	–	not used
F2.4	15	Interior lamp relay
F2.5	10	Voltage in Run or Accessory (overload protected)
F2.6	10	Trailer: Left Turn and Stop if Independent Stop not provided
F2.7	15	Blower motor relay
F2.8	–	not used
F2.9	20	Brake pedal position switch (13480), Multifunction switch (13K359)
F2.10	5	Instrument cluster
F2.11	30	Wiper Control Module (WCM), wiper
F2.12	10	Trailer: Right Turn and Stop if Independent Stop not provided
F2.13	10	ABS control module (2C219)
F2.14	10	Instrument cluster, Hydro max module, Warning buzzer/chime module, Transmission control switch
F2.15	15	Turn relay, left
F2.16	20	Fused battery feed
F2.17	5	Radio (18806), feed
F2.18	–	not used
F2.19	5	Daytime Running Lamps (DRL) relay
F2.20	–	not used
F2.21	15	Turn relay, right
F2.22	–	not used

Fuse	Amps	Circuits protected
F2.23	–	not used
F2.24	–	not used
F2.25	10	Low beam lamp, right front
F2.26	10	Brake shift interlock (3Z719), Speed control servo (9C735)
F2.27	–	not used
F2.28	–	not used
F2.29	–	not used
F2.30	–	not used
F2.31	10	Low beam lamp, left front
F2.32	10	Digital Transmission Range (DTR) sensor (7F293)
F2.33	–	not used
F2.34	–	not used
F2.35	20	High beam lamp, Instrument cluster
F2.36	–	not used
F2.37	–	not used
F2.38	10	Run power circuit
F2.39	–	not used
F2.40	–	not used
F2.41	10	Main light switch (11654)
F2.42	–	not used
F2.43	–	not used
F2.44	–	not used