Battery Junction Box (BJB) (continued)

Maxi–fuse	Amps	Circuits protected
F1.1	30 c.b.	Constant Control Relay Module (CCRM) – 3.8L
	50	Constant Control Relay Module (CCRM) – 4.6L
F1.2	30	Main light switch (11654), Multifunction switch
F1.3	40	Starter relay (11450), Constant Control Relay Module (CCRM), Generic Electronic Module (GEM) (14B205), Transmission control switch, Instrument cluster
F1.4	40	ABS control module (2C219), Instrument cluster, Generic Electronic Module (GEM) (14B205), Power windows, Radio (18806), Windshield wiper motor (17508), Wiper high/low relay
F1.5	40	Restraints control module (14B321), Daytime Running Lamps (DRL) module, Front blower motor, Electronic flasher module
F1.6	40	Electronic flasher module, Radio (18806), Subwoofer amplifier, front, Subwoofer amplifier, rear
F1.7	–	not used
F1.8	50	ABS control module (2C219)
F1.9	20	Power point (19N236)
F1.10	30	Main light switch (11654)
F1.11	30	Rear window defrost relay
F1.12	40	Generic Electronic Module (GEM) (14B205)

Mini–fuse	Amps	Circuits protected
F1.13	30	Subwoofer amplifier, luggage compartment right inboard, Subwoofer amplifier, luggage compartment right outboard
F1.14	20	Constant Control Relay Module (CCRM)
F1.15	30	Subwoofer amplifier, luggage compartment left outboard, Subwoofer amplifier, luggage compartment left inboard
F1.16	20	Horn relay
F1.17	20	ABS control module (2C219)
F1.18	30	Seat adjust switch, driver side front (14A701)
F1.19	–	not used
F1.20	20	Generator
F1.21	–	not used
F1.22	–	not used
F1.23	–	not used
F1.24	20	Constant Control Relay Module (CCRM)
F1.25	–	not used
F1.26	30	Constant Control Relay Module (CCRM)
F1.27	20	Daytime Running Lamps (DRL) module, Fog lamp relay
F1.28	30 c.b.	Convertible top raise relay, Convertible top lower relay