C16 (GN)

14401

P91
Central Junction
Box (CJB)



F10051

Pin	Circuit	Circuit Function
1	15-AJ1 (GN/YE)	Voltage, ignition switch in Start or Run (not overload protected)
2	29S-LF3 (OG/YE) +	Voltage supplied at all times (overload protected), switched
	29S-LF11 (OG/WH)	Voltage supplied at all times (overload protected), switched
3	15-JA10 (GN/OG)	Voltage, ignition switch in Start or Run (not overload protected)
4	29-HA6 (OG/YE)	Voltage supplied at all times (overload protected)
5	15-AJ10 (GN/OG)	Voltage, ignition switch in Start or Run (not overload protected)
6	29S-LF1 (OG/YE)	Voltage supplied at all times (overload protected), switched
7	15-FA13 (GN/RD) +	Voltage, ignition switch in Start or Run (not overload protected)
	15-FA38 (GN/RD)	Voltage, ignition switch in Start or Run (not overload protected)
8	29S-LF4 (OG/BU) +	Voltage supplied at all times (overload protected), switched
	29S-LF20 (OG)	Voltage supplied at all times (overload protected), switched
9	15-LE14 (GN/RD) +	Voltage, ignition switch in Start or Run (not overload protected)
	15-LE29 (GN/BK)	Voltage, ignition switch in Start or Run (not overload protected)
10	15S-HB19 (GN/BU)	Voltage, ignition switch in Start or Run (not overload protected), switched

C17 (GY)

14401

P91
Central Junction
Box (CJB)



F11014

Pin	Circuit	Circuit Function
1	15-KA9 (GN/RD) +	Voltage, ignition switch in Start or Run (not overload protected)
	15-KA19 (GN/OG)	Voltage, ignition switch in Start or Run (not overload protected)
2	29-MD15 (OG/BK)	Voltage supplied at all times (overload protected)
3	15-LD16 (GN/RD)	Voltage, ignition switch in Start or Run (not overload protected)
4	50-BB16 (GY/BK)	Voltage, ignition switch in Start (not overload protected)
5	31S-LC7 (BK/BU)	Ground, switched
6	75-DA1 (YE)	Voltage: Ignition switch in Accessory or Run
7	15-LG23 (GN/WH)	Voltage, ignition switch in Start or Run (not overload protected)
8	29-LE29 (OG/BK)	Voltage supplied at all times (overload protected)
9	29-LG8 (OG)	Voltage supplied at all times (overload protected)
10	–	not used
11	15-LG28 (GN/WH)	Voltage, ignition switch in Start or Run (not overload protected)
	15-LG28 (GN/WH) +	Voltage, ignition switch in Start or Run (not overload protected)
	15-PG13 (GN/YE)	Voltage, ignition switch in Start or Run (not overload protected)