64-1 VEHICLE SPEED SENSOR (VSS)

2003 ESCORT

For diagnostic information, refer to the Powertrain Control/Emissions Diagnosis Manual.



CONNECTOR REFERENCE LIST

CONNECTOR	SECTION-PAGE
C111	13-12
C177	31-3
C212	24-11
C252	62-8

Refer to Location Index, Cell 152, for Component, Connector, Splice, Ground and Base Part Number descriptions and locations.