Four–door model

Item	Part Number	Description
1	12B637	Wiring harness – Engine control sensor + fuel charge
2	13A409	Wiring harness – Rear lamp jumper
4	14290	Wiring harness – Dash panel to headlamp junction
5	14334	Wiring harness – Interior lamp, feed – Super cab
6	14401	Wiring harness – Main
7	14405	Wiring harness – Rear lamp
8	14630	Wiring harness – Window regulator, right front door – with power equipment
9	14631	Wiring harness – Window regulator, left front door – with power equipment
10	14A280	Wiring harness – Cable assembly – Battery
11	14A320	Wiring harness – Headlamp dimmer switch, jumper
12	19A041	Wiring harness – Radio speaker – without power equipment
13	19A044	Wiring harness – Radio speaker, front LH – without power equipment
14	19A041	Wiring harness – Radio speaker – Four–door model
15	19A044	Wiring harness – Radio speaker, front LH – Four–door model
16	–	5R44E Transmission
17	–	5R55E Transmission
18	–	ABS control module (2C219)
19	–	Auxiliary relay box 1
20	–	Battery (10655)
21	–	Battery Junction Box (BJB) (14A003)
22	–	Central Junction Box (CJB) (14A068)
23	–	Central security module
24	–	Daytime Running Lamps (DRL) module
25	–	Generic Electronic Module (GEM) (14B205)
26	–	Powertrain Control Module (PCM) (12A650)
27	–	Restraints control module (14B321)
28	–	Speed control servo (9C735)
29	19A170	Wiring harness – Radio speaker jumper
30	19B113	Wiring harness – Radio amplifier
31	18A919	Wiring assembly – Radio feed