-8


30
P91
Central Junction
Box (CJB)
F23
3A
7-MB17
.75 RD/BK
5
C2
A30
Instrument cluster
6
6) Illumination
4
C2
14-AA17
.75 OG
S64
14-AA17
.75 OG
17
C190
A147
Powertrain control
module (PCM)
14-AA17
.75 OG
2
D23
Diagnostic connec-
tor
1
C133b
31-MB27
.75 BK
18
33
19
C190
9-AA22
.75 BK
1
D20
Data Link Connec-
tor (DLC)
31-DA18
.75 BK
31-DA10
.75 BK
2
31-DA6
.75 BK
C191
S4
G25
G1001
Component number
Name of component
Details about compo-
nent or operation
Splice
Dashed line indicates
terminals for the same
connector
Component connector
number
Wire insulation is one
color
Other circuits which are
also grounded at
G1001, but are not
shown, can be refer-
enced in Ground Dis-
tribution
Ground numbered for
reference to compo-
nent location chart