Item	Part Number	Description
1	12B637	Wiring harness – Engine control sensor and fuel charge
2	12A581	Wiring harness – Engine control sensor
3	14B060	Wiring harness – Starter motor relay and battery ground
4	14A320	Wiring harness – Multifunction switch
5	14401	Wiring harness – Main
6	19B113	Wiring harness – CD changer (18D806)
7	14A005	Wiring harness – Body main
8	14A504	Wiring harness – Body main
9	14B084	Wiring harness – Passenger, driver seat jumper
10	13A625	Wiring harness – High mounted stoplamp
11	14405	Wiring harness – Tail lamps
12	13A576	Wiring harness – Trailer lamp feed
13	A2–765	Wiring harness – Bi–fuel tank 1
14	A2–766	Wiring harness – Bi–fuel tank 2
15	A147	Powertrain Control Module (PCM) (12A650)
16	O1	Battery (10655)
17	O5	Generator
18	A7	ABS control module (2C219)
19	P93	Battery Junction Box (BJB) (14A003)
20	–	Natural Gas Vehicle (NGV) tank
21	–	Natural Gas Vehicle (NGV) tank