33-1 COOLING FAN

2001 CONTINENTAL

For diagnostic information, refer to Powertrain Control/Emissions Diagnosis Manual.



PCM determines when fan operation is required by monitoring engine coolant temperature, and air conditioning status. When operation is required, PCM signals Low and High Speed Cooling Fan Relays to turn on fan to desired speed.

Refer to Location Index, Cell 152, for Component, Connector, Splice, Ground and Base Part Number descriptions and locations.