

C601

RIGHT DOOR LOCK SWITCH

PIN	CIRCUIT	CIRCUIT FUNCTION
1	1205 (BK)	Ground
2	–	NOT USED
3	1297 (YE/RD)	Unlock Feed
4	1205 (BK)	Ground
5	194 (PK)	Power (Accessory Delay Relay Output)
6	–	NOT USED
7	1296 (OG/BK)	Lock Feed
8	–	NOT USED

CONNECTOR REFERENCE LIST

CONNECTOR	SECTION-PAGE
C337	126-6
C338	126-6
C342	59-13
C344	59-14
C346	59-10
C347	59-11
C700	126-9
C800	126-9