

Warning

Do not attempt to diagnose or troubleshoot air bag circuitry without consulting the Workshop Manual. Improper troubleshooting could cause the air bags to deploy inadvertently, causing injury.

CONNECTOR REFERENCE LIST

CONNECTOR	SECTION-PAGE
C190	59-9
C240	60-5
C241	60-6
C346	59-10
C348	59-11

Refer to Location Index, Cell 152, for Component, Connector, Splice, Ground and Base Part Number descriptions and locations.