131-1 PARKING AID

2001 EXPEDITION/NAVIGATOR

For diagnostic information, refer to Section 413-13 of the Workshop Manual.

Refer to Location Index, Cell 152, for Component, Connector, Splice, Ground and Base Part Number descriptions and locations.