### COMPONENT TESTING PROCEDURE

| Connect Battery Positive and Negative to Terminals: | Check Continuity From Terminals: | Continuity Will Be: |
|---|---|---|
| 1 and 2 | 3 to 4 and 3 to 5 | From 3 to 5 only |
| – | 1 to all others | To 2 only |
| – | 3 to all others | To 4 only |

### TERMINALS




### SCHEMATIC

**RELAY**
CONTACTS CHANGE POSITION WITH CURRENT THROUGH COIL