
FROM S134
PAGE 23-3
G
361 RD
12V (START OR RUN)
C1032
71
SOLID STATE
91 34 64 49 50 59
POWERTRAIN CONTROL MODULE (PCM)
151–1 A5
C1032
970 DG/WH
C1028
TURBINE SHAFT SPEED (TSS) SENSOR
151–2 B10
2
1
C1028
359 GY/RD
Y
TO S125
PAGE 23-5
199 LB/YE
944 DG/OG
1012 OG/BK
972 BK/WH
TRANSMISSION CONTROLS
PAGE 29-3
359 GY/RD
F
FROM S125
PAGE 23-5
The frequency from this sensor supplies the PCM with turbine shaft speed information. This information is used in determining EPC pressure and torque converter engagement schedules.