
HOT AT ALL TIMES
3
30A
BATTERY JUNCTION BOX
PAGE 13-3
SEE POWER DISTRIBUTION
PAGE 13-3
196 DB/OG
S212
196 DB/OG
12V
C246
8
MAIN LIGHT SWITCH
PAGE 13-21
SEE PAGE 149-2 FOR SWITCH TESTING
OFF
HEAD
AUTO
PARK
7
9
C246
1525 LG/RD
SEE POWER DISTRIBUTION
PAGE 13-21
15 RD/YE
S244
15
RD/YE
FOG LAMPS
PAGE 86-1
15 RD/YE
15 RD/YE
J
D
A
FROM C216
PAGE 87-1
FROM HEADLAMP RELAY
PAGE 87-1
TO C253
PAGE 87-3