C238 (GY)

14A005
14A488



F10025

14630



F10009

C240 (GY)

14401

N114
Fog lamp switch



F06088

Pin	Circuit	Circuit function
1	–	not used
2	–	not used
3	477 (LB/BK)	Fog lamp switch, to front fog lamp, Relay
4	57 (BK)	Ground
5	235 (RD/BK)	Instrument illumination, input
6	478 (TN/OG)	Fog lamp switch, to front fog lamp