

C395

VIDEO CASSETTE PLAYER

PIN	CIRCUIT	CIRCUIT FUNCTION
1	1002 (BK/PK)	Power (Hot in Acc or Run)
2	–	NOT USED
3	–	NOT USED
4	–	NOT USED
5	A (BK)	IR In
6	1803 (WH)	Audio Out L+
7	1805 (RD)	Audio Out R+
8	1807 (WH)	Video Out
9	–	NOT USED
10	–	NOT USED
11	48	Drain
12	B (BK)	IR Ground
13	1804 (LG)	Audio L–
14	1806 (BK)	Audio R–
15	1808 (BK)	Video Ground
16	694 (BK/LG)	Ground



C960

VIDEO MONITOR

PIN	CIRCUIT	CIRCUIT FUNCTION
1	1002 (BK/PK)	Power (Hot in Acc or Run)
2	–	NOT USED
3	–	NOT USED
4	–	NOT USED
5	A (BK)	IR In
6	1803 (WH)	Audio In L+
7	1805 (RD)	Audio In R+
8	1807 (WH)	Video In
9	–	NOT USED
10	–	NOT USED
11	–	NOT USED
12	B (BK)	IR Ground
13	1804 (LG)	Audio L–
14	1806 (BK)	Audio R–
15	1808 (BK)	Video Ground
16	694 (BK/LG)	Ground