-9

Number	Description	Basic color
1	Audio signal positive	WH
2	Audio signal negative	GY
3	Audio signal reference (return/ shield)	BN
4	Data link, bus positive	GY
5	Data link, bus positive	BU
6	Data link, bus shield	NO
7	Constant DC voltage, other than battery	YE
8	Sensor signal (X–direction, forward, upward)	WH
9	Sensor signal return (reference/ ground)	BN
10	Sensor signal (Y–direction, reverse, downward)	GY
15	Battery voltage, hot in Start and Run only	GN
20	Battery voltage, hot in Run only	PK
29	Battery voltage, hot at all times (secondary fused)	OG
30	Battery voltage, hot at all times (not fused and primary fused)	RD
31	Ground	BK
32	Switched between: Battery voltage, Ground or Open (Plus for: front down, open, mirror leftward, unlock, on)	WH
33	Switched between: Battery voltage, Ground or Open (Plus for: front up, close, mirror rightward, lock, off)	YE
34	Switched between: Battery voltage, Ground or Open (Plus for: rear up, mirror upward, forward or module settings)	BU
35	Switched between: Battery voltage, Ground or Open (Plus for: rear down, mirror downward, reverse or inductor output voltage)	VT
48	Drain wire	NO
49	Pulsed power feed	BU
50	Battery voltage, hot in Start only	GY
59	AC Power	GY
64	DC voltage, hot only if engine runs	BU
75	Battery voltage, hot in Run and Accessory only	YE
91	Ground	BK