Fuse	Amps	Circuits protected
F2.1	25	Radio (18806), Subwoofer amplifier (18C804), F2.31
F2.2	5	Powertrain Control Module (PCM) (12A650), Instrument cluster, Trip Computer Module (10D898), Electronic Automatic Temperature Control (EATC) module (19980), Clock (15000), Navigation display unit (10E899), Audio Visual Navigation (AVN) module (10E887)
F2.3	20	Cigar lighter, front (15055), Data Link Connector (DLC) (14489)
F2.4	7.5	Driver seat module (14C718), Mirror turn signal relay, left, Mirror turn signal relay, right, Seat adjust switch, driver side front (14A701), Adjustable pedal switch, Exterior rear view mirror switch (17B676), Memory set switch (14776)
F2.5	15	Digital Transmission Range (DTR) sensor (7F293), Speed control servo (9C735)
F2.6	5	Generic Electronic Module (GEM) (14B205), Steering position sensor (18B015), Instrument cluster, Air suspension module (3C142), Parking Aid Module (PAM) (15K866), Electronic Compass (19A548), Auto park brake release switch (2B623), Brake shift interlock
F2.7	5	Rear blower motor relay
F2.8	5	Generic Electronic Module (GEM) (14B205), Clock (15000), Tonneau cover control module (14B450), Audio Visual Navigation (AVN) module (10E887)
F2.9	–	not used
F2.10	–	not used
F2.11	30	Windshield wiper motor (17508), Windshield washer relay, Wiper run/park relay, Wiper high/low relay
F2.12	15	Air suspension service switch (5K761)
F2.13	20	Brake pedal position switch (13480), Indicator flasher relay (13350)
F2.14	15	Battery saver relay, Interior lamps relay

Fuse	Amps	Circuits protected
F2.15	5	Generic Electronic Module (GEM) (14B205), Brake pedal position switch (13480), Brake pressure switch (2B264)
F2.16	20	Headlamp circuit, High beam
F2.17	10	Exterior rear view mirror, driver side (17682), Exterior rear view mirror, passenger side (17683), Rear window defrost switch (18578)
F2.18	5	Clock (15000), Main light switch (11654), Audio Visual Navigation (AVN) module (10E887)
F2.19	–	not used
F2.20	5	Tonneau cover control module (14B450), Driver seat module (14C718), Air suspension module (3C142)
F2.21	15	Digital Transmission Range (DTR) sensor (7F293), F1.15
F2.22	10	Restraints control module (14B321)
F2.23	10	ABS control module (2C219), Climate controlled seat module, driver side, Climate controlled seat module, passenger side, Electrochromatic inside mirror unit (17700), Indicator flasher relay (13350), Rear Integrated Control Panel (RICP) (19980), Trailer tow relay, battery charge, Traction control switch
F2.24	10	Electronic Automatic Temperature Control (EATC) module (19980), Blower motor relay, F2.7
F2.25	–	not used
F2.26	10	Headlamp, right (13008)
F2.27	5	Main light switch (11654), Fog lamp relay
F2.28	10	Headlamp, left (13008)
F2.29	5	Central security module, Autolamp sensor, Overdrive cancel switch (7G550)
F2.30	30	Instrument cluster, Passive anti–theft transceiver module (15607), PCM power relay, Spark plugs
F2.31	10	CD changer (18D806), Rear Integrated Control Panel (RICP) (19980)