92-1 EXTERIOR LAMPS

2001 TOWN CAR

For diagnostic information, refer to Section 417-01 of the Workshop Manual.

*** PARK LAMP OR HEADLAMP SWITCH CLOSED**
**** HEADLAMP SWITCH CLOSED**