


engine compartment, 7.3L Diesel

B2	Manifold Absolute Pressure (MAP) sensor	A 2
B41	Camshaft position sensor (6B288)	E 3
B213	Intake Air Temperature (IAT) sensor (12A697)	E 5
B279	Exhaust Back Pressure (EBP) sensor	F 3
C110		A 4
C129		E 5
C180		E 3
C1076		A 2
C1087		A 2
C1100a		F 3
C1119		A 1
C1247		E 2
C1249a		F 4
C1271		F 3
C1272		A 3
C1360		A 3
G100		A 5
G101		B 5
G102		F 2
G108		F 1
G109		E 4
M278	Vacuum pump motor	A 1
O1	Battery (10655)	F 3
O3	Battery II	F 4
R32	Fuel heater	A 2
Y249	Injection Pressure Regulator (IPR)	A 3
Y252	Electronic Shift On the Fly (ESOF) solenoid	E 2
Y265	Exhaust Pressure Regulator (EPR)	A 3