

CONNECTOR REFERENCE LIST

CONNECTOR	SECTION-PAGE
C122	29-4
C210	13-13
C212	24-11
C220	13-14

Refer to Location Index, Cell 152, for Component, Connector, Splice, Ground and Base Part Number descriptions and locations.