Item	Part Number	Description
1	12A654	Wiring harness – Engine coolant temperature sensor (A/C)
2	12B637	Wiring harness – Engine control sensor and fuel charge
3	13105	Wiring harness – Headlamps
4	13407	Wiring harness – Rear lamp, LH side
5	13407	Wiring harness – Rear lamp, RH side
6	13410	Wiring harness – Rear lamp, LH side
7	13410	Wiring harness – Rear lamp, RH side
8	13412	Wiring harness – Rear license plate lamp
9	14290	Wiring harness – Dash panel to headlamp junction
10	14297	Wiring harness – windshield, wiper, feed
11	14334	Wiring harness – Interior lamps
12	14401	Wiring harness – Main
13	14405	Wiring harness – Tail lamps
14	14406	Wiring harness – Fuel tank sender
15	14407	Wiring harness – Fuel tank gauge sender
16	14A005	Wiring harness – Body main
17	14A032	Wiring harness – Police auxiliary junction box, rear
18	14A227	Wiring harness – Luggage compartment, jumper
19	14A411	Wiring harness – jumper, Main
20	14A699	Wiring harness – Power seats
21	14B060	Wiring harness – Starter motor relay and battery ground

Item	Part Number	Description
22	14B079	Wiring harness – Console Panel
23	15080	Wiring harness – Cigar lighter illumination lamp
24	15A219	Wiring harness – Turn lamps, LH side
25	15A219	Wiring harness – Turn lamps, RH side
26	7C078	Wiring harness – Transmission control selector neutral switch
27	–	ABS control module (2C219)
28	–	Air suspension module (3C142)
29	–	Battery Junction Box (BJB) (14A003)
30	–	Central Junction Box (CJB) (14A068)
31	–	Daytime Running Lamps (DRL) module
32	–	Electronic Automatic Temperature Control (EATC) sensor
33	–	Emergency flasher relay block
34	–	Lighting control module
35	–	Natural Gas Vehicle (NGV) module
36	–	Police auxiliary junction box, front
37	–	Police auxiliary junction box, rear
38	–	Powertrain Control Module (PCM) (12A650)
39	–	Restraints control module (14B321)
40	–	Variable Assist Power Steering (VAPS) module
41	–	Battery
42	–	Instrument cluster