
1
2
3
4
5
6
7
8
A
B
C
D
E
F
C813
Speaker, right middle
C816
Side door ajar
switch, right
C817
Side door lock
actuator, right
C313
14026
14014
C314
front of vehicle

hinged door