

Cell 12 – Charging System
Cell 20 – Starting System
Cell 21 – Engine Ignition
Cell 23 – Engine Controls – 3.8L
Cell 24 – Engine Controls – 4.6L 2V
Cell 31 – Vehicle Speed Control
Cell 33 – Cooling Fan
Cell 42 – ABS
Cell 81 – Wipers and Washers

Cell 46 – Air Bags
Cell 120 – Power Seats
Cell 122 – Power Lumbar Seats

Cell 89 – Courtesy Lamps
Cell 103 – Convertible Top

Cell 56 – Rear Window Defrost

Cell 113 – Luggage Compartment Lid Release

Cell 90 – Turn/Stop/Hazard Lamps
Cell 92 – Exterior Lamps
Cell 93 – Reversing Lamps

Cell 100 – Power Windows
Cell 110 – Power Door Locks
Cell 124 – Power Mirrors
Cell 111 – Remote Keyless Entry (RKE)

Cell 85 – Headlamps
Cell 86 – Fog Lamps
Cell 90 – Turn/Stop/Hazard Lamps
Cell 92 – Exterior Lamps
Cell 97 – Daytime Running Lamps

Cell 29 – Transmission Controls

Cell 37 – Shift Lock
Cell 44 – Horn/Cigar Lighter
Cell 54 – Air Conditioner/ Heater
Cell 59 – Multifunction Electronic Control Modules
Cell 66 – Warning Devices
Cell 71 – Illumination
Cell 112 – Anti–Theft
Cell 130 – Radio

Cell 14 – Module Communications Network
Cell 60 – Audio System – General Information