

CONNECTOR REFERENCE LIST

CONNECTOR	SECTION-PAGE
C230a	81-4
C273a	13-38

Refer to Location Index, Cell 152, for Component, Connector, Splice, Ground and Base Part Number descriptions and locations.