

1
2
3
4
5
6
7
8
A
B
C
D
E
F
C290a
C290b
Radio (18806)
C2099
Passenger Air bag Deactivation (PAD) switch
C294a
C2089
Adjustable pedal switch
C284
Four–wheel drive switch
C241
Rear window defrost switch (18578)
C2033
Power point, instrument panel (19N236)
C2003
C2159
Adjustable pedal motor (2C429)
C2035
Parking aid disable switch (15A860)
C294c
Function selector switch assembly, front
C294b
C2031
Cigar lighter, front (15055)
C294d
front of vehicle
dash panel, center