PIN	CIRCUIT	CIRCUIT FUNCTION
31	–	NOT USED
32	G032 (WH)	Signal Return
33	–	NOT USED
34	G034 (WH)	NOT USED
35	–	NOT USED
36	–	NOT USED
37	–	NOT USED
38	G038 (WH)	NOT USED
39	–	NOT USED
40	–	NOT USED
41	–	NOT USED
42	G042 (WH)	Fuel Pump
43	G043 (WH)	Fuel Level Input
44	–	NOT USED
45	G045 (WH)	Injector #3
46	G046 (WH)	Indicator Light Switch Return
47	G047 (WH)	Injector #4
48	–	NOT USED
49	G049 (WH)	Injector #5
50	G050 (WH)	Indicator Light Switch Return
51	G051 (WH)	Injector #6
52	G052 (WH)	NOT USED
53	G053 (WH)	Injector #7
54	G054 (WH)	NOT USED
55	G055 (WH)	Injector #8
56	G056 (WH)	NOT USED
57	G057 (BK)	Ground
58	G058 (WH)	NOT USED
59	G059 (BK)	Ground
60	G060 (WH)	NOT USED
61	G061 (BK)	Ground
62	G062 (BK)	Ground
63	G063 (BK)	Ground
64	G064 (BK)	Ground



C4059

LPG SENDER RELAY #1

PIN	CIRCUIT	CIRCUIT FUNCTION
30	G006 (DG)	FSP
85	G119 (BK)	Relay Ground
86	G115 (WH)	Tank Select
87	G006-2 (LG)	FSP-2
87A	G006-1 (DG)	FSP-1