C420 (BK)

14405

E105
Reversing lamp, left



F02108

Pin	Circuit	Circuit Function
1	31-LG9 (BK)	Ground
2	15S-LG9A (GN/BK)	Voltage, ignition switch in Start or Run (not overload protected), switched

C421 (BK)

14405

E109
Reversing lamp, right



F02108

Pin	Circuit	Circuit Function
1	31-LG16 (BK)	Ground
2	15S-LG16 (GN/OG)	Voltage, ignition switch in Start or Run (not overload protected), switched