
1 2 3 4 5 6 7 8
A
B
C
D
E
F
C703
Power window motor, left rear (23394)
C803
Power window motor, right rear (23394)
C701
Window adjust switch, left rear (14A412)
C801
Window adjust switch, right rear (14A412)
C311
C313
C804
Door lock actuator, right rear (218A42)
C704
Door lock actuator, left rear (218A43)
14405
Wiring harness – Tail lamps
19A017
14632
Wiring harness – rear door
C702
Speaker, left rear (18808)
C802
Speaker, right rear (18808)
front of vehicle
rear door