

CONNECTOR REFERENCE LIST

CONNECTOR	SECTION–PAGE
C182	29-5, 30-5
C243	13-28
C250	13-25

Refer to Location Index, Cell 152, for Component, Connector, Splice, Ground and Base Part Number descriptions and locations.