F1.5 -1


15
F1.5
15A
P93
Battery Junction
Box (BJB)
15) Hot in start or
run
34 18 LB/OG
42 C134
34 18 LB/OG
34 18 LB/OG
1 C1195
P133
Vapor manage-
ment valve
S111
34 18 LB/OG
1 C171
B48
Heated Oxygen
Sensor (HO2S)
#11
34 18 LB/OG
1 C141
B87
Heated Oxygen
Sensor (HO2S)
#22
34 18 LB/OG
1 C172
B47
Heated Oxygen
Sensor (HO2S)
#21
34 18 LB/OG
1 C142
B88
Heated Oxygen
Sensor (HO2S)
#12
Duratec engine