C114

* Marauder

12B637

Coil On Plug (COP)
4 (12A366)



F02331

Pin	Circuit	Circuit function
1	16 (RD/LG)	Voltage supplied in Start and Run (overload protected)
	*1030 (DG/VT)	Coil On Plug (COP) 4 (12A366), control
2	1030 (DG/VT)	Coil On Plug (COP) 4 (12A366), control
	*16 (RD/LG)	Voltage supplied in Start and Run (overload protected)

C115

* Marauder

12B637

Coil On Plug (COP)
5 (12A366)



F02331

Pin	Circuit	Circuit function
1	16 (RD/LG)	Voltage supplied in Start and Run (overload protected)
	*1021 (LG/YE)	Coil On Plug (COP) 5 (12A366), control
2	1021 (LG/YE)	Coil On Plug (COP) 5 (12A366), control
	*16 (RD/LG)	Voltage supplied in Start and Run (overload protected)