Harnesses

14A488 .....F3
14A609 .....G4
14A584 .....F7

C Numbers

C355 Power seat switch, right A2
C602 Door ajar switch, right front.....D7
C603 Door lock actuator, right front.....E7
C605 Door lock switch, passenger side.....A5
C608 Power window motor, right front.....B5
C610(F) In-line (14A584 to 14A488) G5
C610(M) In-line (14A488 to 14A584) G5
C611(F) In-line (14A488 to 14A699).....C7
C611(M) In-line (14A699 to 14A488).....C7
C612 Speaker, right front.....B2
C622 Exterior rear view mirror, right.....A4
C635 Climate controlled seat switch, passenger side.....A4