
Hot in Run/Start
F2.24
15A
Central Junction Box (CJB) (14A068)
Hot at all times
F1.101
30A
Power Distribution Box (PDB)
Splice pack
Air ABS relay
Hot in Run/Start
F2.29
15A
Central Junction Box (CJB) (14A068)
CJB-F29 adapter
Instrument cluster
Less ABS
With ABS
Ground adapter #1
Engine diagnostic conn
Auto traction control
Auto traction control switch
Air ABS ECU #1 & Air ABS ECU #2
Ground adapter #1
Air ABS wheel sensor, left
Air ABS wheel sensor, right
Wheel speed sensor, left (rear)
Wheel speed sensor, right (rear)
ABS modulator, left
ABS modulator, right
Modulator, left (rear)
Modulator, right (rear)