
1 2 3 4 5 6 7 8
A
B
C
D
E
F
12B637
C194
Ignition transformer capacitor 2 (18801)
C171
Heated Oxygen Sensor (HO2S) #11 (9F472)
C1299
Barometric Absolute Pressure (BAP) sensor
C174
Ignition transformer capacitor 1 (18801)
C1072
EGR vacuum regulator solenoid (9J459)
C1046
C1186
Fuel injector 6 (9F593)
C140
C197a
Starter motor (11002)
C197b
Starter motor (11002)
C1292
Supercharger bypass solenoid
12A581
C128
Mass Air Flow (MAF) sensor (12B579)
Battery Junction Box (BJB) (14A003)
C192
C1100a
Battery (10655)
12A581
C1100b
Battery (10655)
14B060
C103
Oil pressure switch (9278)
14290
G102
C1021
Headlamp, left (13008)
front of vehicle

Cobra