Pickup

Item	Part Number	Description
1	12A581	Wiring harness – Engine control sensor
2	12B637	Wiring harness – Engine control sensor and fuel charge
3	12A690	Wiring harness – Engine control sensor extension
4	14B060	Wiring harness – Starter motor relay and battery ground
5	14300	Wiring harness – Battery output
6	14305	Wiring harness – Alternator/Rectifier system
7	14B060	Wiring harness – Starter motor relay and battery ground
8	14401	Wiring harness – Main
9	14A005	Wiring harness – Body main
10	14B084	Wiring harness – Seat regulator
11	14B084	Wiring harness – Seat regulator
12	15525	Wiring harness – Powertrain Transmission Control Systems
13	17C712	Wiring harness – Rear view inside mirror
	15A404	Wiring harness – Marker lamp to switch
14	14405	Wiring harness – Tail lamps
15	19F504	Wiring harness – running board lamps
16	13412	Wiring harness – Rear license plate lamp

Item	Part Number	Description
17	13A409	Wiring harness – Tail lamps
18	13A576	Wiring harness – Trailer lamp feed
19	14B102	Wiring harness – Cylinder head sensor jumper
20	14N139	Wiring harness – Parking/Reversing Aid
21	13K027	Wiring harness – DTRL kit
22	15A211	Wiring harness – Fog lamp jumper
23	15K867	Wiring harness – Parking aid sensor, front
24	–	Battery (10655)
25	–	Battery II
26	–	Auxiliary relay box 1
27	–	Auxiliary relay box 2
28	–	Powertrain Control Module (PCM) (12A650)
29	–	Central Junction Box (CJB) (14A068)
30	–	Vehicle Security Module (VSM)
31	–	Electronic Automatic Temperature Control (EATC) module (19980)
22	–	Four–wheel drive control module
33	–	Parking Aid Module (PAM) (15K866)