
All wires are 57 (BK) unless otherwise noted.
* W/MEMORY SEATS
LEFT VANITY MIRROR/ LAMP SWITCH PAGE 89-1
ROOF OPENING PANEL CONTROL SWITCH PAGE 101-1
RIGHT VANITY MIRROR/ LAMP SWITCH PAGE 89-1
DAY/NIGHT MIRROR/ AUTOLAMP SENSOR PAGE 87-1
COMPASS/ OUTSIDE AIR TEMPERATURE MODULE PAGE 102-1
FUEL TANK ASSEMBLY PAGE 62-1
REAR GATE SOLENOID PAGE 41-2
REAR FILL SOLENOID PAGE 41-2
AIR SUSPENSION CONTROL COMPRESSOR ASSEMBLY PAGE 41-1
C304
C900M
C900F
C303
C341
C902
C342M
C342F
151–16 A4
S202
C311M
C311F
C429
C428
430 GY
C430F
C430M
S351
151–17 E1
C119F
C119M
G204
LEFT FRONT HEATED SEAT MODULE PAGE 119-1
DRIVER SEAT MODULE (DSM) PAGE 123-2
LEFT FRONT POWER SEAT CONTROL SWITCH PAGE 120-1
LEFT POWER LUMBAR MOTOR PAGE 122-1
LEFT REAR DOOR AJAR SWITCH PAGE 66-2
LEFT REAR POWER WINDOW SWITCH PAGE 100-3
LEFT FRONT DOOR AJAR SWITCH PAGE 66-2
LEFT REAR DOOR AJAR SWITCH PAGE 66-2
C370
C350
C349F
C349M
*C347
C704
C702
C506
C704
C141F
C141M
151–17 F1
S700
*S321
*C346M
*C346F
C361M
C361F
C323F
C323M
C258F
C258M
C326F
C326M
LESS POWER EQUIPMENT GROUP
MEMORY SEAT SWITCH PAGE 123-2
SAFETY BELT WARNING SWITCH PAGE 66-1
C245M
C245F
C324F
C324M
S235
H
FROM S500 PAGE 10-9
J
FROM S302 PAGE 10-10
K
FROM S301 PAGE 10-11
G204