

C608 (BLACK)

RIGHT FRONT POWER DOOR LOCK SWITCH

PIN	CIRCUIT	CIRCUIT FUNCTION
1	57 (BK)	Ground
2	–	NOT USED
3	120 (PK/LG)	Right Switch (Unlock)
4	57 (BK)	Ground
5	19 (LB/RD)	Switch Illumination
6	119 (PK/YE)	Right Switch (Lock)
7	–	NOT USED



C508 (BLACK)

LEFT FRONT POWER DOOR LOCK SWITCH

PIN	CIRCUIT	CIRCUIT FUNCTION
1	57 (BK)	Ground
2	–	NOT USED
3	120 (PK/LG)	Left Switch (Unlock)
4	57 (BK)	Ground
5	19 (LB/RD)	Switch Illumination
6	119 (PK/YE)	Left Switch (Lock)
7	–	NOT USED

CONNECTOR REFERENCE LIST

CONNECTOR	SECTION-PAGE
C256	117-4
C257	117-4