C30

14014



F10048

A42
Driver air bag module

Pin	Circuit	Circuit Function
1	15S-HC8 (GN/RD)	Voltage, ignition switch in Start or Run (not overload protected), switched
2	15S-HC7 (GN/BU)	Voltage, ignition switch in Start or Run (not overload protected), switched
3	31S-GE52 (BK/RD)	Ground, switched
	15S-HC7 (GN/BU)	Voltage, ignition switch in Start or Run (not overload protected), switched
4	31-GE52 (BK)	Ground
	31-HC8 (BK)	Ground
5	15S-JA33 (GN/BU)	Voltage, ignition switch in Start or Run (not overload protected), switched
6	91S-JA33 (BK/BU)	Ground, switched
7	29-AH6 (OG/YE)	Voltage supplied at all times (overload protected)
8	31-DA14 (BK) +	Ground
	31-HC8 (BK)	Ground
9	15S-JA37 (GN/BK)	Voltage, ignition switch in Start or Run (not overload protected), switched
10	91S-JA37 (BK/GN)	Ground, switched