For diagnostic information, refer to the Powertrain Control/Emissions Diagnosis Manual.

PICKUP

* START OR RUN