Master window adjust switch (14529)

Schematic



N447
Master window adjust switch (14529)
0) Rest
1) Driver
2) Passenger
3) Left rear
4) Right rear
5) Up
6) Down
7) One–touch down
8) Lock

Terminals

C504a



F08167

C504b



F06239