BATTERY CHARGING—POSSIBLE BATTERY OVERCHARGE WHILE USING NGS TESTER—ELECTRIC RANGER ONLY	Article No. 99-16-7

FORD: 1998-2000 RANGER

ISSUE

Whenever an electric Ranger is on-plug, it is possible to "overcharge" the Ranger EV battery pack if the New Generation Star (NGS) Tester is used to place the Battery Control Module (BCM) into any of the active command modes. The NGS Tester should never be left connected to an unattended vehicle while on-plug.

ACTION

The NGS Tester should never be left connected to an unattended vehicle while on-plug because of the potential to overcharge battery modules. If NGS Tester is disconnected per these instructions there is no concern.

WARNING

WHEN THE NGS TESTER IS USED AND THE BCM IS IN ACTIVE COMMAND MODES, IT CAN OVERHEAT THE BATTERY MODULES AND MAY START A FIRE IN THE BATTERY PACK AND VEHICLE SYSTEMS.

CAUTION

SHOULD ANY OF THE ACTIVE COMMAND MODES ACCIDENTLY BE ENTERED WHILE THE VEHICLE IS ON-PLUG, THE CHARGE PLUG SHOULD BE IMMEDIATELY REMOVED FROM THE CHARGE INLET AND THE NGS TESTER DISCONNECTED FROM THE VEHICLE. AFTER THE CHARGE PLUG HAS BEEN REMOVED AND THE NGS TESTER DISCONNECTED, THE VEHICLE CAN BE PUT BACK ON CHARGE WITHOUT THE RISK OF OVERCHARGING THE BATTERY PACK.

OTHER APPLICABLE ARTICLES: NONE
WARRANTY STATUS: INFORMATION ONLY
OASIS CODES: 203000, 203100