TRACTION BATTERY—BATTERY DIAGNOSTIC SYSTEM—SERVICE TIP	Article No. 00-11-1

FORD: 1998-2000 RANGER

ISSUE

The Battery Diagnostic procedure presently written in the Workshop Manual calls for the use of Battery Diagnostic System (BDS). Using BDS in battery packs with Battery Control Module (BCM) software version 3.3.1 and BCM part number (XL5F-10B687-BH) and higher will over-discharge the battery pack and is therefore not recommended.

ACTION

Refer to the following Service Procedure for proper procedures to follow.

SERVICE PROCEDURE

Please note that this is a two-phase process.

Phase One

1. Discharge the traction battery until the Power Limit Light begins to flash, preferably by driving the vehicle.

NOTE
BATTERY MODULE VOLTAGE INFORMATION MUST BE GATHERED WITHIN 5 MINUTES OF COMPLETING DISCHARGE OF TRACTION BATTERY.

2. Using New Generation Star (NGS) Tester, select the correct year and model for the vehicle being tested.
3. Select Diagnostic Data Link.
4. Select Battery Control Module.
5. Select Active Commands Modes.
6. Select Battery Module Select.
7. Press #8 Setup button.
8. Select Auto and hit Cancel button.
9. Press #7 PIDS button and highlight BAT_MV.
10. Hit start button.
11. Press trigger and rotate knob to view each battery module. Scroll through each battery module and record the information on the Battery Data Information Sheet (Figure 1). Please make copies of Figure 1 before filling out for future use.

Phase Two

1. Press Cancel (Exit current menu).
2. Select Battery Module Select and press enter.
3. Press the Setup button and select Auto Send. Press Cancel.
4. Press #7 (PIDS) and select BAT_MC and SOC. (Note: Do Not select BAT_SOC).
5. Press start.
6. Press trigger and scroll through the Battery Modules recording information on the existing Data Information Sheet. Fax the recorded information to 1-313-248-4753 and a Service Engineer will contact you with the appropriate course of action. If you have issues or concerns, contact E.V. Service Engineering for evaluation at 1-800-852-5280 or 1-313-337-3822.

OTHER APPLICABLE ARTICLES: NONE
WARRANTY STATUS: INFORMATION ONLY
OASIS CODES: 203000, 290000

Vehicle Data Information

Environmental Vehicle Center
Service Engineering
15050 Commerce Drive North
Dearborn, Michigan 48120
(800) 852-5280
(313) 248-4753 Fax

VIN#

Mileage

DTE

SOC (Gauge)

Charger PN#

TIM PN#
Self Test Codes

IAA PN#
Self Test Codes

BCM PN#
Self Test Codes
On-Demand Codes

	BAT_MC	BAT_MV	SOC		BAT_MC	BAT_MV	SOC
1.				21.			
2.				22.			
3.				23.			
4.				24.			
5.				25.			
6.				26.			
7.				27.			
8.				28.			
9.				29.			
10.				30.			
11.				31.			
12.				32.			
13.				33.			
14.				34.			
15.				35.			
16.				36.			
17.				37.			
18.				38.			
19.				39.			
20.							

TB-6066-A

Figure 1 - Article 00-11-1