SUSPENSION—REAR SHOCK SPACER WASHER USAGE—ELECTRIC VEHICLES (E.V.) PRODUCED AFTER 4/1/2001 ONLY	Article No. 01-13-3

FORD: 2001 RANGER

ISSUE

Beginning April 2001 some EV Rangers and EV Postal built chassis vehicles have a 1/2 ″ inner diameter stainless steel AN (aircraft numerical) washer used as spacers on either side of the rear shock absorber lower mount. The spacers are typically .030″-.060 ″ thick, and may be used on either or both sides. These spacers are required to reduce the deflection of the aluminum mounting flanges when the lower shock absorber mounting nut is torqued on the bolt. Use caution when disassembling these vehicles to determine if the shims are installed on the vehicle.

ACTION

Verify during rear axle and shock reassembly that the spacers removed are reinstalled. Refer to EV Ranger Workshop Manual section 204-02-1 for rear axle removal and installation procedures.

WARNING

FAILURE TO RE-INSTALL THESE SHIMS WHERE NECESSARY MAY CAUSE CRACKING OF THE ALUMINUM MOUNTING FLANGES WHEN THE LOWER SHOCK ABSORBER MOUNTING NUT IS TORQUED ON THE BOLT. CRACKED FLANGES WILL REQUIRE DISASSEMBLY OF THE REAR AXLE FROM THE VEHICLE FOR REPAIR OR REPLACEMENT.

OTHER APPLICABLE ARTICLES: NONE
WARRANTY STATUS: INFORMATION ONLY
OASIS CODES: 304000

Copyright © 2001 Ford Motor Company