Configuration (MD 14516 USER_DATA_PLC_ALARM)

4500	;	Signals from NCK [r8]							
Data block	1	NCK interface> PLC							
Byte									
4500 3000	Alarm reaction/ deletion criterion Alarm 700000								
4500 3001	Alarm reaction/ deletion criterion Alarm 700001								
up to									
4500 3031		Alarm reaction/ deletion criterion Alarm 700031							

Note:

Information on PLC alarms, including configuring user alarms, can be found in:

References:

Up Guide", Section "PLC alarms"

5.11 Reading and writing PLC variables

4900		PLC variables [r/w]								
Data block			PLC interface							
Byte										
4900 0000		Offset[0]								
4900 0001		Offset[1]								
up to										
4900 1021										
4900 1022		Offset[1022]								
4900 1023		Offset[1023]								

Note:

The application programmers of NCK and PLC themselves are responsible for the organization of this data area. Data type, position offset and meaning of the variables must be agreed. The memory range limits per data type must be observed (1, 2 or 4 byte types). Further information can be found in:

References:

"Operation and Programming", Section "Reading and writing PLC variables"