
Kindle + KOREader

A layperson handoff guide

Send books, read PDFs comfortably, connect by SSH, and always return to the normal Kindle interface.

Prepared for this device

Kindle Paperwhite 10th generation (PW4)

Firmware 5.18.1; Sanctuary jailbreak; KPM; KOREader kindlehf

Last observed address: 192.168.1.109; KOREader SSH port: 2222

lazing.art • flow.lazing.art

Contents

1	Start here	2
1.1	What is installed	2
1.2	What KOREader can open	2
2	Moving between KOREader and the normal Kindle	2
2.1	Enter KOREader	2
2.2	Return to the normal Kindle interface	2
2.3	Autostart and the recovery switch	2
3	Send books by USB cable	3
3.1	Books placed on this Kindle	3
3.2	Keep sidecar folders when backing up	3
4	Recommended: use Kindle Book Sender	3
4.1	Recommended first connection: no-password Wi-Fi bootstrap	4
4.2	USB pairing fallback	4
4.3	Every wireless transfer after pairing	4
4.4	Platform notes	4
5	Send books over Wi-Fi with SSH	4
5.1	Before connecting	4
5.2	Open a shell from Windows	5
5.3	Send books wirelessly	5
5.4	Manual SCP command	5
5.5	Use WinSCP instead of commands	5
6	Where files live	5
7	Everyday KOREader use	6
7.1	Open menus and books	6
7.2	Make a PDF easier to read	6
7.3	Useful PDF controls	6
7.4	Rotate the screen	6
7.5	Highlights, notes, and dictionaries	7
8	Return to the normal Kindle system	7
8.1	Normal exit	7
8.2	If KOREader is unresponsive	7
8.3	Recovery marker	7
9	Dedicated handoff SSH key	7
9.1	Important warning	8
9.2	Install the public key again over USB	8
9.3	Revoke this key	8
9.4	Embedded private key	8
10	Troubleshooting	8
11	Safe maintenance	9
12	Package contents	9
13	References	9

1 Start here

The easiest everyday workflow

1. In KOREader, open the File Browser.
2. Find books under `/mnt/us/documents/`.
3. To add books with a cable, exit KOREader first, connect USB, and copy into the Kindle's `documents` folder.
4. To add books over Wi-Fi, start KOREader's SSH server and use the included `send-books-to-kindle.ps1`.
5. To return to Amazon's normal Kindle interface, choose **Exit KOREader**. It does not remove KOREader or the jailbreak.

1.1 What is installed

Component	Purpose
Sanctuary	The jailbreak used on firmware 5.18.1. It installed the modern Kindle package stack.
KPM	Kindle Package Manager. KOREader was installed with <code>;kpm install koreader</code> .
KOREader	The reading application. This device uses the <code>kindlehf</code> build because firmware 5.16.3 and later is hard-float.
SSH server	KOREader's Dropbear SSH server, normally on TCP port 2222. It permits command-line access and wireless file transfer while KOREader is running.

1.2 What KOREader can open

KOREader supports PDF, EPUB, DJVU, MOBI, CBZ/CBT, DOCX, RTF, HTML, TXT, XPS, FB2, PDB, CHM, Mark-down, images, and several archive formats. Amazon books can still be read in the normal Kindle interface. KOREader is especially useful for PDFs, technical documents, multilingual material, comics, and sideloaded EPUB files.

2 Moving between KOREader and the normal Kindle

2.1 Enter KOREader

If the native Kindle Home screen is visible, tap the **KOREader** document/scriptlet in the library. KPM launches KOREader with the correct hard-float package.

2.2 Return to the normal Kindle interface

1. Tap near the top edge of the KOREader screen to reveal the top menu.
2. Open the main or hamburger menu.
3. Choose **Exit KOREader**.
4. Wait for the native Kindle Home screen to reappear.

Exit is not uninstall. Your books, settings, highlights, jailbreak, KPM, and KOREader remain installed. Open the KOREader library item whenever you want to return.

2.3 Autostart and the recovery switch

Autostart must always be optional. The safe design for this device uses two marker names at the visible USB root:

<code>ENABLE_KOREADER_AUTOSTART</code>	Allows one KOREader launch after boot.
<code>DISABLE_KOREADER_AUTOSTART</code>	File or folder that overrides the enable marker and keeps the normal Kindle interface.

The final autostart job must wait at least 30 seconds, check the disable marker both before and after the delay, launch only once, and never respawn KOREader. Therefore choosing **Exit KOREader** returns to the normal interface for the rest of that boot.

Current handoff state: autostart is disabled. A first experimental boot hook did not bring networking back reliably. The visible `ENABLE_KOREADER_AUTOSTART` marker was removed and `DISABLE_KOREADER_AUTOSTART` was created. Do not remove the disable marker until the replacement KMC-based hook has been installed and tested.

3 Send books by USB cable

USB is the simplest and most reliable method.

1. In KOREader, choose **Exit KOREader**.
2. Connect the Kindle to the computer with a data-capable USB cable.
3. Open the drive named **Kindle**.
4. Open the `documents` folder.
5. Create a clear folder such as `documents/Books` OR `documents/LinguaLeaf/en-main-blackwhite`.
6. Copy the book files into that folder.
7. Use Windows **Safely Remove Hardware / Eject** before unplugging.
8. Open KOREader and browse to the same folder.

KOREader may not expose normal USB mass storage while it controls the screen. If the Kindle drive does not appear, exit KOREader and reconnect the cable.

3.1 Books placed on this Kindle

The following five bilingual black-and-white PDFs were copied into `/mnt/us/documents/LinguaLeaf/en-main-blackwhite/`:

- A Game of Thrones
- A Clash of Kings
- A Storm of Swords
- A Feast for Crows
- A Dance with Dragons

3.2 Keep sidecar folders when backing up

KOREader commonly stores per-book progress, highlights, notes, and settings in a neighboring folder ending in `.sdr`. When moving or backing up an annotated book, copy both the book and its matching `.sdr` folder.

4 Recommended: use Kindle Book Sender

For a layperson, the easiest method is the free Kindle Book Sender desktop app:

<https://lachlanchen.github.io/Kindle/>

The website automatically recommends the correct download for Windows, Ubuntu/Linux, or macOS. The app removes the need to find an IP address, type SSH commands, or choose between SFTP and SCP.

4.1 Recommended first connection: no-password Wi-Fi bootstrap

1. Download and open Kindle Book Sender from the website.
2. In KOREader, stop SSH if it is already running, enable **Login without password (DANGEROUS)**, then start SSH again.
3. Enter the address and port displayed by KOREader, such as 192.168.5.26:2222. A hostname, IPv6 address, or another routed private subnet also works.
4. Check **First connection: KOREader allows login without password**, then click **Connect / find Kindle**.
5. The app creates a new RSA key for that computer, connects without a password once, installs only its public key, and verifies a second connection with the key.

The app-generated private key stays in that computer's user application-data folder. A new computer can repeat the no-password bootstrap without installing Python, SSH tools, or a key manually. The app does not disable KOREader's no-password option; leaving it enabled is convenient but allows any reachable client to attempt root access.

4.2 USB pairing fallback

Exit KOREader first so the Kindle drive can appear. Connect USB, click **Pair over USB**, safely eject, reopen KOREader, and start SSH. If KOREader remains open and the drive does not appear, use no-password Wi-Fi bootstrap instead; USB alone cannot modify storage that the Kindle has not exported to the computer.

4.3 Every wireless transfer after pairing

1. Put the Kindle and computer on the same trusted Wi-Fi, or on networks that can route to each other.
2. Open KOREader, then start **Tools > SSH server**.
3. In the app, click **Connect / find Kindle**.
4. Drag books into the app or choose them with the file picker.
5. Click **Send books**.

The app always tests a supplied address first, including hostname, IPv4, IPv6, custom port, and routed subnet addresses. It then scans every active private IPv4 interface as a fallback. A candidate is accepted only after authentication and confirmation that `/mnt/us/koreader` exists. Failures distinguish DNS, routing, closed port, timeout, passwordless rejection, and key rejection. Books are placed in `/mnt/us/documents/Books`; SFTP is used when available and SCP is selected automatically as a fallback.

4.4 Platform notes

- **Windows:** open the downloaded `.exe`. If SmartScreen appears, choose **More info**, then **Run anyway**.
- **Ubuntu/Linux:** extract the archive, allow the application file to run as a program, then open it.
- **macOS:** choose Apple Silicon or Intel on the website. Because the community build is not notarized, Control-click the app and choose **Open** the first time.

If discovery does not succeed, enter the exact address shown when KOREader SSH starts. Guest Wi-Fi and access-point client isolation can block two devices even when the Wi-Fi name is identical. On Windows, the app can request a UAC-approved outbound firewall rule, but that rule cannot repair router isolation or a missing route.

5 Send books over Wi-Fi with SSH

5.1 Before connecting

1. Connect the computer and Kindle to the same trusted Wi-Fi network.
2. Open KOREader on the Kindle.
3. Open the top menu, choose **Tools**, then **SSH server**.
4. Start the SSH server and keep KOREader open while transferring.

- Note the Kindle's IP address. This guide uses 192.168.1.109 as an example; DHCP may assign a different address later.

KOREader's SSH service uses port **2222**, user **root**, and the dedicated key supplied with this package. It is separate from ordinary Windows Remote Desktop and from port 22.

5.2 Open a shell from Windows

Open PowerShell in the Handoff folder and run:

```
.\connect-kindle.cmd 192.168.1.109
```

The equivalent manual command is:

```
ssh -i .\keys\kindle_handoff_rsa -p 2222 root@192.168.1.109
```

The first connection may ask whether the host key is trusted. Confirm only after checking that the address belongs to your Kindle on your own local network.

5.3 Send books wirelessly

Use the supplied PowerShell helper:

```
.\send-books-to-kindle.ps1 -KindleIp 192.168.1.109 "C:\Books\Example Book.pdf"
```

To send several books, add each full path as another quoted argument. The helper creates /mnt/us/documents/Books if needed and uses legacy SCP mode for compatibility with KOREader's Dropbear SSH server.

5.4 Manual SCP command

```
scp -O -i .\keys\kindle_handoff_rsa -P 2222 "C:\Books\Example.pdf" root@192.168.1.109:/mnt/us/documents/Books/
```

SSH uses lowercase -p; SCP uses uppercase -P. The -O option selects the older SCP transfer protocol supported reliably by this Kindle setup.

5.5 Use WinSCP instead of commands

For drag-and-drop transfer, create a WinSCP site with:

Setting	Value
File protocol	SFTP first; if unavailable, select SCP
Host name	Kindle IP, for example 192.168.1.109
Port number	2222
User name	root
Password	Leave empty
Private key	Handoff\keys\kindle_handoff_rsa
Remote folder	/mnt/us/documents/Books

If WinSCP reports that SFTP is unavailable, change the protocol to **SCP**. It is acceptable to let WinSCP convert this dedicated key to PPK format.

6 Where files live

Kindle path	Purpose
/mnt/us/documents/	Books visible to the native library and KOREader
/mnt/us/documents/Books/	Recommended general KOREader book folder
/mnt/us/documents/LinguaLeaf/	Current LinguaLeaf collection

<code>/mnt/us/koreader/</code>	KOREader application; do not casually rename or delete
<code>/mnt/us/koreader/settings/</code>	KOREader preferences and SSH settings
<code>/mnt/us/koreader/settings/SSH/authorized_keys</code>	Public keys allowed to log in
<code>/mnt/us/DISABLE_KOREADER_AUTOSTART</code>	Safety marker preventing automatic launch
<code>/mnt/us/ENABLE_KOREADER_AUTOSTART</code>	Future opt-in marker; do not create until a safe launcher is tested

The USB drive letter, such as F:, is selected by Windows and can change. The Linux path `/mnt/us` always means the user-visible Kindle storage.

7 Everyday KOREader use

7.1 Open menus and books

- Tap near the **top edge** to open KOREader's top menu.
- Tap near the **bottom edge** to open reading controls.
- In the file browser, enter `documents`, then tap a book.
- Tap the left or right side to move backward or forward.
- Long-press text for highlighting, dictionary lookup, search, or notes.

7.2 Make a PDF easier to read

1. Open the bottom reading menu.
2. Choose a crop mode to remove white margins.
3. Try **Fit width** for ordinary single-column pages.
4. Rotate to landscape when the page is too wide.
5. For text-heavy PDFs, enable **Reflow** so KOREader rearranges text to fit.

Reflow works best when the PDF contains a real text layer. A scan made only from page images may need OCR first. Reflow can disturb tables, equations, footnotes, and complex layouts; turn it off for those pages.

7.3 Useful PDF controls

- **Crop**: removes margins and enlarges print.
- **Fit width**: fills the screen horizontally.
- **Columns**: reads multi-column pages in sequence.
- **Landscape**: gives wide pages more space.
- **Contrast**: darkens faint scans.
- **Dewatermark**: can reduce pale backgrounds.
- **Auto-straighten**: corrects tilted scans.
- **Panel zoom**: helps with comics and image panels.
- **OCR**: supports selection or lookup from image text where available.

7.4 Rotate the screen

Open the reading menu and choose the rotation or orientation icon. Select portrait or landscape. Rotation is stored per book.

7.5 Highlights, notes, and dictionaries

- Long-press and drag across text, then choose **Highlight** or **Add note**.
- Use the bookmark control to mark the current page.
- Use the table of contents, page search, or text search from the top menu.
- Long-press a word for dictionary lookup after dictionaries are installed.
- KOREader stores progress, highlights, and book settings in a nearby folder ending in `.sdr`. Back up each book together with its `.sdr` folder.

Other features include adjustable typography for reflowable books, night mode, warm-light controls when supported, reading statistics, gestures, profiles, collections, OPDS catalogs, Wallabag, calibre wireless access, and cloud-storage plugins.

8 Return to the normal Kindle system

8.1 Normal exit

1. Tap the top edge to open KOREader's menu.
2. Open the main or tools menu.
3. Choose **Exit KOREader**.

This returns to Amazon's native Kindle interface.

8.2 If KOREader is unresponsive

Hold the power button until the device restarts; this can take roughly 40 seconds. Because automatic launch is currently disabled, the Kindle should return to the native interface.

8.3 Recovery marker

While the Kindle is connected by USB, ensure this file or folder exists at the top level of the drive:

`DISABLE_KOREADER_AUTOSTART`

Remove `ENABLE_KOREADER_AUTOSTART` if it exists. A safe future launcher must always let the disable marker override the enable marker.

9 Dedicated handoff SSH key

This package contains an RSA 3072-bit key pair made only for this Kindle:

Item	Value
Private key	Handoff\keys\kindle_handoff_rsa
Public key	Handoff\keys\kindle_handoff_rsa.pub
Comment	AgInTi-Flow-Kindle-Handoff-ONLY
Fingerprint	SHA256:Q/RgMY4wzHjQYuC3sfHDykwp8ejp9C7wyfAZLE80MJE
Private-file SHA-256	D278BB1D9BB278371B4CFD162C4F6139F64D7AD079584F560B6CED57F4DF3B50
Passphrase	None, for simple appliance-style access

The public key must be present in KOREader's SSH authorization file before this handoff key can connect. Verify it or run the included USB installer. The private key is not a default Windows SSH key; supplied commands select it explicitly with `-i`.

9.1 Important warning

This private key is intentionally exposed in this PDF. Use it only for this Kindle. Never authorize it on Windows, Linux computers, servers, routers, GitHub, cloud accounts, or another device. Anyone holding this PDF can access the Kindle whenever KOReader SSH is running and reachable.

Copy the private-key file to a trusted computer only when its user should control this Kindle.

9.2 Install the public key again over USB

.\install-public-key-usb.ps1

The helper locates the mounted Kindle and appends the key only if it is absent.

9.3 Revoke this key

Open /mnt/us/koreader/settings/SSH/authorized_keys, delete the line ending in AgInTi-Flow-Kindle-Handoff-ONLY, then restart KOReader’s SSH server. Deleting one copy of the private key does not revoke other copies; removing the public-key line does.

9.4 Embedded private key

Below is the complete Kindle-only private key. Prefer the separate file because copying from a PDF can alter characters or line endings.

```
-----BEGIN OPENSSH PRIVATE KEY-----
b3B1bnNzaC1rZXktZjEAAAAABG5vbmUAAAAEbm9uZQAAAAAAAAABAAABlwAAAAZdc2gtcn
NhAAAAAwEAAQAAAYEA2neq13LIz1my1v02fc9o18QMvzemiQMYR1m101hPXpu+n8yC+Kry
Mu10nSpK/pV/jiF02YUPFGNcPCeFu3dg1GyFJx+D3DpCwacINK4EtK/E2VhMmB9e2fsXT
OzDCOYTc3g0S41JyDz3uiHHPJKhcFN8hf0QZ6C5+KTj1BbjHb9hNlmeckKj4ML2nUG+qX
/ipsUvyIKQzQuCEf2uyxqPL+TePpGdnSXNY1XkRKfMr1FkwVA251kXfzs2qn9VPALBQf
jf4tktcA1Mu6yak7z0FNBBGjW932R9JxJh/NrA6TsKzaBgGSaDBVC7eFNwE+yKeeechMM
W+s+JFgG3SXjAwX8x8GHRyW7ZVE3AR+c3Md3nfiE+A0u1aVQxGgO6Tbs8IrmXbxQgRCMu
G+wwj28p0Coh4y7P5KUcUI7GerjSD8R7QFb050H2dym2TUEySU0FNqSjyvE4hMDJD0sW3
vb0hjUSUKNvBZz1IpSCWtLFtaDnERuoEXksK1nC9AAAFmBxxvFecb8XxAAAAAB3NzaC1yc2
EAAAGBANp3qtdyM9Zspb9Nn3PaNFEDL83poqjGEZpdyNTY16bvp/Mgviq8jLpTp0qSrF6
VF44hdNmFdxRjXDwnn1N3YNRshScfg9w6QsGnCDsULSVxN1YTJgFxtn7F0zswjmeE3N4N
EuNScg897ohxzySoXBTfIX4TkGegkvik49QW4x2/YTS5nnICo+DC9p1Bvq1/4qbFL81JEM
0LNB8drssasTy/k3j6RnZ01zV2JVSzK5X5MFQNuZZFxc7Nqp/VTwCwUH43+LXLXANTL
usmp089BTQW2xiCpd9kfScSYfzawOk7Cs2gRoEmgwVQ3hTcBPSinnnnITDFvrPiRaht01
4wMMFMFBh62Fu2VRNwEfnN4DHd534hPgDrpW1UMRoDuk27PCK5128UIEQJLhvsL42tvkdA
qIeMuz+SlHFCOxnq40g/Ee0BWzudB9ncptk1BMk1NBTKo8rx0ITAYQ9LfT729IY1LFJDb
wWc9SKUg1rSxbWg5xEbqBF5LctZwvQAAAAABAAEAAAGAKaYSrcw20EFzaJGRZ964s8myDG
pB18CMci1hda+SQgkTCEfm2B102yHbWN8NK5HP/w0rhie5x94MRvG4ZU8I4dybSw61gbMMW
2oFCf0FvI9EdmEcFhqMaiQJA72vBwJiwmnSbXYWfoHwJwF82cVBGAMXFZD31NAfmEAY+Kb
hH1wguVPVMvrmVn14A2LEmPMQ2gb/4ssFuD6kPybngseHZSTF6+2H6QM9sI3aXvc1/wQ70
wHBtLeVq8fMeEdG6FDr93Jf91tgNTrxfciXiq+jrjX3qNwXSh5MhGoNnsq7kIYOyGa80km
ESYFjyRTLGF3X1KMN8BnTviox4NSuBU+EKrasEmXqo1gFXAk5ibTtOUK+KvXxdSYnczkrng
SNPFFtOP/CcCTCGC68vtpo3AXoc8rWEUvGAfQyQ0FTqWEtxOzTa3Yf1j7JnLzmOX7FEd5R
1HqMfAXL4A9whqYueABY1bMX1ImH0CC+TqVTGm8p5xHnyAyktFQBNSAcOJZuqMkQ3BAAAA
wGmpLW1l+1GoNQcZksCj32gYn3deNgDuuNZmkID1EXdTHN1f5p5A1Wg8pOJtB5H8UBj8R
xdJIKTDPOJEAkQQvsNvdqApfTkOHnAabN8owDS9wEJKF4VEzZSLvJLaDHRfBg85wvku61D
bRVB3hV7d+KXyrGmNPLw0XM50nex8x1WnuV3ysyh9BxHef+vjpPyKR8bIQ1UimUg1DeQ07
1EMwEC1ZVs6QiMKUAR9R24X9vCDUYPXot58cB39++TyW0vQAAAAAMEA+GGadzYQQ0010+aR
jq1kNc3r9gXfESBznfM0ZGW6G8B5gYAEftqhn/Y62X+1cwUXq3Z28/B/YowwP4EGC15d0
6hkp+8HHCAkUzyJmld/rngBT9Ck+mkaodGjxhcxQUOt/UBu5Fj1RqQdnGg2tMBDTcdpSrV
Gp8fKpA0CypZMRnctytnws8vc/umIt06rmR4z2d15M/7D1I0KqVcOH2zP/nxX5ejNyOuqEN
D3D+HxK1aR0i9paW5Woeu2F9k1SN1AAAAwQDhKyr3ET44e+X51y19N9deG8mjzLQp5mId
1CuLE7zRmRJ/VmXe4BJ9fZIA0nE3yGpg1yU1PovG3M9HfPcmePXUSROIIFGuwVUPkk/L03
bne82CvkduTm/IUKf4dBpPAVsrw+L7HABVsd/a89CrdZNIjQ1yWnrNRszDdxhrQvBtsb2vR
D6ABewtzzJOPGgN70c0+9abmstAD27cy9Ji00FdrokM8IGXwjC6beGqOvtEpgv6I5BjR
A2t1h1p6krVyKAAAAAQWdjb1RpLUZsb3ctS2luzGxL1UhhbmRvZmZtY05MwQECawQ=
-----END OPENSSH PRIVATE KEY-----
```

10 Troubleshooting

Symptom	Action
Connection timed out	Confirm the same Wi-Fi, current IP, running KOReader SSH, and port 2222.

Connection refused	Start SSH from KOREader and keep KOREader running.
Permission denied	Select the key with <code>-i</code> ; reinstall its public key over USB if needed.
Host identification changed	Verify the device first, then run <code>ssh-keygen -R [192.168.1.109]:2222</code> .
SFTP unavailable	Use SCP in WinSCP or add <code>-o</code> to <code>scp</code> .
Book missing	Put it under <code>documents</code> , eject safely, then refresh the file browser.
PDF text tiny	Crop, fit width, rotate to landscape, or try reflow.
Bad reflow	Disable it and use crop, landscape, columns, or OCR.
Need native Kindle	Exit KOREader; if stuck, reboot and retain the disable marker.

11 Safe maintenance

- Keep airplane mode on when network access is unnecessary.
- Safely eject the Kindle in Windows before unplugging USB.
- Do not delete jailbreak preservation files, `koreader`, `KUAL/KPM` components, or unfamiliar top-level files.
- Back up `documents`, KOREader settings, and all `.sdr` folders before major changes.
- Do not install Amazon firmware until its jailbreak compatibility is checked.
- Stop KOREader SSH after wireless administration.

12 Package contents

File	Purpose
<code>kindle-koreader-handoff.pdf</code>	Printable guide
<code>kindle-koreader-handoff.tex</code>	XeLaTeX source
<code>connect-kindle.cmd</code>	One-command Windows SSH
<code>send-books-to-kindle.ps1</code>	Wireless book transfer
<code>install-public-key-usb.ps1</code>	Idempotent public-key installer
<code>ssh-config.example</code>	Optional SSH alias template
<code>build-guide.ps1</code>	Rebuilds this PDF
<code>keys/kindle_handoff_rsa</code>	Kindle-only private key
<code>keys/kindle_handoff_rsa.pub</code>	Matching public key

13 References

- KOREader User Guide: https://koreader.rocks/user_guide/
- KOREader source: <https://github.com/koreader/koreader>
- KindleModding KOREader guide: <https://kindlemodding.org/jailbreaking/post-jailbreak/koreader.html>
- Sanctuary documentation: <https://kindlemodding.org/jailbreaking/Sanctuary/>
- AgInTi Flow: <https://flow.lazying.art>
- LazyingArt LLC: <https://lazying.art>

Prepared by AgInTi Flow, LazyingArt LLC

<https://flow.lazying.art> • <https://lazying.art>

Handoff edition dated July 16, 2026